


Brant Bed Assembly Instructions

Contents: sizes vary depending on model ordered

- A** ≈ 1 headboard (36" tall)
- B** ≈ 1 footboard (18" tall)
- C** ≈ 2 bed rails (75" long)
- D** ≈ 4 slats (twin = 40-1/4", full = 55-1/4")
- E** ≈ 1 posture board (twin = 2 pcs, full = 3 pcs)
- F** ≈ 8 connector bolts
- G** ≈ 8 cross dowels
- H** = 8 wood screws
- I** = 1 Allen key

Tools required:

Slotted screwdriver, #2 Robertson or Phillips screwdriver



Please read all instructions before beginning

1. Assemble bed using 2 bed rails **C**, 1 headboard **A**, 1 footboard **B**, 8 connector bolts **F**, with 8 cross dowels **G**. Refer to "Figure 1" for correct position of bed rail, bed end and hardware.
2. Slide 4 slats **D** into bed rail grooves and secure each slat with 2 wood screws **H** using predrilled holes. Refer to "Figure 2". Position 1 slat 1/2" from each bed end and 2 evenly spaced in between.
3. Place a posture board **E** onto the bed assembly. (Twin – 2 pieces, full – 3 pieces.)

